

## Task Seating Cleaning & Maintenance

### Aluminium and Steel

These will be chrome plated, bright polished or powder coated depending on the components and finishes of your chair. These parts can be cleaned with a damp cloth and in the case of polished or chrome parts, buffed dry with a soft non-abrasive cloth to prevent streak marks. For chrome plated finishes, stubborn stains can be removed using a metal cleaner. Do not use abrasive cleaning agents in case of damage.

### Mesh

**(Ara, Do, Eva, Joy, Kirn)**

Vacuum regularly and occasionally wipe clean with a damp cloth.

### Plastic

Wipe with a damp cloth periodically. Dust can gather in some hard to reach areas, particularly between the seat and back of task chairs. Stubborn stains (pen etc.) may require a mild household cleaning agent to remove - particularly on light coloured plastic components. Do not use any abrasive cleaning products on plastic parts as these may damage the surface.

### Nylon Parts

Wipe with a damp cloth periodically.

### Leather & Fabric Upholstery

Please refer to manufacturing cleaning guidelines.

### Minimise the risk of damage:

- Avoid over exposure to direct sunlight.
- Avoid exposure to excessive heat from a fire, radiator or local high temperature light sources.

### Warranty

Warranty and guarantee periods commence from delivery to site and are subject to fair wear and tear. Retention of the warranty label attached to the product will support claim authenticity when quoting the relevant N number.

Orangebox warrants exclusively to the original purchaser of our products that all products (based upon a normal 8 hour working day) will be free from defects and structurally sound for a period of five years from date of manufacture. Only approved fabrics listed in our yearly price list are covered and all materials are subject to fair wear and tear in use. This is reduced to 18 months warranty for 24 hour use or 24 months warranty for 12 hour use environments. Warranty for power modules is as per the manufacturer's warranty. All service parts carry a 1 year warranty.

Under no circumstances should a silicone polish or wax be used as these damage the finish and prevent the furniture from being refinished. Please note that we cannot be held responsible for any product to which polish has been applied.

Please contact your Orangebox representative with any queries.