formetiq

SEATING


Oslo


Mesh back cantilever base meeting chair CHC2001



UNPACKING INSTRUCTIONS

- Do not use a knife or sharp object to open the carton.
- Carefully open the carton, remove the contents and lay them out on cardboard or other protective surface to avoid damage.
- Check package contents against the Parts List on the next page to ensure that all components have been received.
- Do not use damaged or defective parts, report any discrepancies within 48 hours of receipt of goods.
- Carefully read and understand all instructions before attempting assembly, see notes on back page.





Ī	Ö	O	,	Ŭ	Í
			0		
EG AME	HEX KEY	M6 X 20 SCREW	M6 X 30 SCREW	6MM FLAT WASHER	8MM FLAT WASHER
l	I	6	4	4	4

Assembly Hints & Tips

- 1. Unpack on a soft surface (carpet or cardboard) and identify all parts and fixings.
- 2. Read and understand the instructions.
- 3. Have tools ready for the job, Hexagon key, (supplied)
- 4. To avoid cross threading screws, start all threads by hand, not with power drill.
- 5. Always start all the screws in a component loosely first before tightening. E.g. when fitting the arm start all screws before tightening any.
- 6. Always tighten screws equally to prevent uneven stress and misalignment of components.
- 7. Double check final tightness of all fixings before use.

Maintenance & Care

- 1. Hard surfaces should be regularly wiped with a micro fibre cloth or similar.
- 2. Soft furnishing should be regularly vacuumed using a brush type upholstery attachment.
- 3. Wet spills should be immediately blotted dry and treated with a proprietary upholstery cleaner as directed.
- 4. A check of all screws and fasteners during the first month of use and periodically thereafter is advisable.